

Kodak EasyShare printer dock 6000



User's Guide

Visit Kodak on the World Wide Web at www.kodak.com



Eastman Kodak Company

343 State Street


Rochester, New York 14650

© Eastman Kodak Company, 2003

Kodak and EasyShare are trademarks of Eastman Kodak Company.


P/N 6B8312

Front View




- | | |
|-------------------------|----------------------|
| 1 Printer dock | 7 Print mode button |
| 2 Universal insert | 8 Print mode lights |
| 3 Color cartridge light | 9 Transfer button |
| 4 Print button | 10 Paper light |
| 5 Arrow keys | 11 Slide show button |
| 6 Paper tray | 12 Camera connection |

Back View




- 1 USB connector
- 2 DC power connector
- 3 Paper path

Side Views



- 1 Color cartridge slot
- 2 Color cartridge door



- 1 A/V out connector



Table of Contents

1	Getting Started with Your Printer Dock	1
	Need This Guide in Larger Print?.....	1
	What Can I Do With My Printer Dock?	1
	Printer Dock Package Contents	2
	Finding a Location for the Printer Dock.....	3
	Installing the Camera Insert.....	4
	Connecting the Power	5
	Loading the Color Cartridge.....	6
	Loading the Paper.....	7
	Inserting the Paper Tray.....	8
	Indicator Lights and Buttons.....	9
2	Getting Started with Your Camera	11
	Loading the Camera Battery	11
	Setting Picture Quality	12
	Docking and Charging the Camera.....	13
3	Printing Without a Computer	15
	Printing from Your Camera	15
	Removing Perforated Tabs from Prints	16
	Canceling Printing	17
4	Reviewing Pictures and Videos	19
	Running a Slide Show.....	19

Displaying Pictures and Videos on a Television.....	20
5 Using the Printer Dock with a Computer	23
System Requirements.....	23
Installing the Software	24
Connecting to a Computer.....	26
Transferring Pictures	27
Printing from a Computer	28
Removing Perforated Tabs from Prints	30
Status Monitor—Windows only.....	31
Canceling Printing.....	31
Ordering Supplies.....	32
6 Care and Maintenance	33
General Care.....	33
Cleaning the Print Head.....	34
Clearing a Paper Jam.....	35
Clearing a Color Cartridge Jam	36
Cleaning the Printer Dock.....	36
Traveling with your Printer Dock.....	37
7 Troubleshooting	39
Printing Problems.....	39
Problems Transferring Pictures	46
Printer Dock Status Lights.....	47
8 Getting Help	51
Helpful Web Links.....	51

Help in this User's Guide	51
Software Help	51
Telephone Customer Support	52
9 Appendix	55
Printer Dock Specifications	55
Upgrading Your Software and Firmware	56
Accessories and Supplies	57
Safety Labels	58
Regulatory Information	58
Disposal Information	59

1 Getting Started with Your Printer Dock

Need This Guide in Larger Print?

For a large print version of this User's Guide:

- 1 Go to the support page at www.kodak.com/go/printerdock.
- 2 Under Manuals/Guides, View PDF, click your language to open the User's Guide.
- 3 With the User's Guide open on a Windows-based computer:
 - From the File menu, select Print.
 - In the Print window, select Fit to Page.With the User's Guide open on Mac OS X:
 - From the File menu, select Page Setup.
 - Change Scale to 200%.
- 4 Print as usual.

What Can I Do With My Printer Dock?

Use the Kodak EasyShare printer dock 6000 to make high-quality 4 x 6 in. (102 x 152 mm) photos, with or without a computer.

The printer dock works with Kodak EasyShare CX/DX 6000 series and LS600 series digital cameras.

Without a computer, you can:


- Print pictures directly from your camera
- View a slide show on your television

- Print from a slide show on your television
- Charge your camera battery pack

With a computer, you can:

- Transfer pictures from your camera to the computer
- Organize, edit, and print pictures

Printer Dock Package Contents




- 1 Printer dock
- 2 Universal insert (**installed**)
- 3 Paper tray
- 4 Kodak EasyShare Ni-MH rechargeable battery pack *
- 5 AC power cord
- 6 AC power adapter
- 7 Sample color cartridge (10 pictures)
- 8 Sample photo paper pack(10 Pack)
- 9 Print head cleaning tool
- 10 Welcome kit; includes user's guide**, quick start guide, registration card, and Kodak EasyShare printer dock 6000 software CD

To purchase accessories see a retail dealer of Kodak products or visit www.kodak.com/go/printerdock.

*The EasyShare Ni-MH rechargeable battery pack is for use with selected EasyShare digital cameras (see Loading the Camera Battery, page 11). If your camera uses a EasyShare Li-Ion rechargeable battery, it will be included with your camera.

**In some countries, the user's guide is provided only on CD.

Finding a Location for the Printer Dock




- Allow 5 inches (12.7 cm) clearance on all sides of the printer dock.
- Place the printer dock on a flat, clean, dust-free surface, out of direct sunlight.
- Make sure airflow around the top and back is not blocked.
- Do not place the printer dock on cloth or carpeted surfaces.
- Avoid areas where ventilation ducts, open doors, or frequent passersby might expose the printer dock and paper to high levels of dust and debris. Airborne dirt particles can cause image-quality problems.

Installing the Camera Insert

The printer dock comes with a universal camera insert installed, which is used to fit the camera to the printer dock. The universal insert is used with most cameras.

If your camera comes with a custom insert, use that one instead of the universal insert. Do not discard the universal insert.

- 1 To remove the universal insert:
 - a Push the insert towards the front of the printer and lift up the back edge.
 - b Push the insert towards the rear of the printer and lift out the front edge.
- 2 To Install the custom insert (included with your camera) See your camera manual.
 - a Place the front tabs on the insert in the slots in the printer dock.
 - b Fit the back of the insert down into the dock and snap the insert into place.



NOTE: To order a custom insert for your camera, visit our Web site at www.kodak.com/go/accessories.


Connecting the Power



CAUTION:

Use only the AC adapter and power cord included with the printer dock. Other adapters and cords can damage your camera, printer dock, or computer.

IMPORTANT: Remove your camera from the printer dock when you are connecting power.



Bottom View

- 1 Connect the AC power cord to the adapter, then to the back of the printer dock.
- 2 Connect the AC power cord into a power outlet.


NOTE: Your power cord may be different from the one pictured. Use the plug that accommodates your type of power outlet.

- 3 Route the cable along the channels located on the underside of the printer dock, so that the cable does not interfere with the paper path.


Loading the Color Cartridge

The color cartridge provides the dyes and a protective laminate coating for making your photos.


A sample Kodak color cartridge & photo paper kit (10Pk) are included with the printer dock. To purchase a color cartridge, photo paper kit, and other accessories, see a retail dealer of Kodak products or visit www.kodak.com/go/printerdock.



- 1 Open the color cartridge door on the side of the printer dock.



- 2 Remove the slack in the color cartridge by pushing in on the spool, then rotating the cartridge spool in the direction of the arrow.



- 3 Slide the color cartridge in, label side up and with the arrow pointing toward the printer dock, until it locks into place.



CAUTION:

Do not force the cartridge into the slot.


- 4 Close the color cartridge door.

Handling and Storing the Color Cartridge

- For best quality prints, store the cartridge in a location where the temperature does not exceed 85 °F (30 °C).
- To avoid fingerprints, handle the color cartridge by the spool ends.
- Store the color cartridge away from direct sunlight.

Loading the Paper

IMPORTANT: To avoid getting fingerprints on the paper, handle the paper by the edges or by the perforated tabs.



- 1 Remove the protective cap from the paper tray. Do not discard.
- 2 Lift the paper tray cover.




CAUTION:

Use the upper limit line inside the paper tray as a guide to avoid overloading the paper. Do not load more than 25 sheets. Do not load paper that is missing perforated tabs. Use only the Kodak color cartridge & photo paper kit PH-40. Do not use inkjet paper.

- 3 Load a pack of paper (20 sheets) into the paper tray, with the Kodak logo side facing down.
- 4 Close the paper tray cover.

Inserting the Paper Tray




- 1 Open the paper tray door.
- 2 Slide the paper tray in until the tray locks into place.
- 3 Replace the protective cap on the front of the paper tray to catch the completed prints.

Handling and Storing the Paper

- Do not touch the glossy side of the paper.
- Store the paper away from direct sunlight.

Indicator Lights and Buttons

The lights and buttons on the printer dock indicate the status of the printer dock and the camera, as well as printing options based on the configuration of your camera. For Troubleshooting information, see Printer Dock Status Lights, page 47.



	Lights/Buttons	Function:
1	Cartridge light	Indicates the color cartridge needs replacing.
2	Battery light	Indicates battery charge levels, for rechargeable batteries.
3	Print button	Used to print pictures directly from your camera without a computer.
4	Arrow keys	Used to select the number of copies to be printed. Used to advance through pictures in current mode, tagged mode, print all mode, and slide show mode.
5	Print Mode button	Used to select available print modes: Tagged, Current, All, Index.
6	Print Mode lights	Indicates print selection: Tagged, Current, All, Index.
7	Transfer button	Used to transfer pictures to a computer.
8	Paper light	Indicates paper tray is empty or jammed.
9	Slide Show button	Used to run a slide show on your television or camera display.




2 Getting Started with Your Camera

Loading the Camera Battery

NOTE: The battery pack is not charged when you receive it. The battery needs to be completely charged before using your camera.

Which Battery Do I Use?

IMPORTANT: *The printer dock charges only the provided Kodak EasyShare Ni-MH rechargeable battery pack and Li-Ion rechargeable battery (included with some cameras). If you use any other batteries, rechargeable or not, no charging takes place.*

If your camera came with:	Install this rechargeable in your camera:
<p data-bbox="125 790 493 817">Non-rechargeable starter batteries:</p> <div data-bbox="142 833 487 984"><p data-bbox="146 935 267 984">CRV3 Lithium, 3V</p><p data-bbox="311 872 348 896">OR</p><p data-bbox="430 929 487 984">2, AA 1.5V</p></div>	<p data-bbox="524 786 919 850">The Ni-MH rechargeable battery pack that came with your printer dock.</p> <div data-bbox="664 872 731 1008"></div> <p data-bbox="607 1014 850 1040">Ni-MH rechargeable</p>

If your camera came with a Li-Ion rechargeable battery:

Install the **Li-Ion rechargeable** battery in your camera.



Li-Ion, 1050 mAh

OR



Li-Ion, 1700 mAh

Do **not** use the Ni-MH battery pack that came with the printer dock.

Setting Picture Quality

Your printer dock uses Best (3:2) aspect ratio for printing pictures. To take advantage of the aspect ratio and make sure your pictures are not cropped when printed, set your camera's Picture Quality as follows.




Best (3:2) ★★★

See your camera user's guide for details on Setting Picture Quality.


Docking and Charging the Camera

Docking your camera lets you make prints directly from the camera, transfer pictures from the camera to the computer, and charge the camera battery.

- 1 Make sure the battery is installed in the camera. See your camera user's guide for details.




- 2 On the camera bottom, locate the connector.




- 3 Place the camera in the printer dock and push down to seat the connectors.

Charging begins when camera enters auto power-off. See your camera user's guide for details.

The camera is now powered by the printer dock instead of the camera battery.



- The Kodak EasyShare Ni-MH rechargeable battery pack and Li-Ion rechargeable batteries take 2.5 to 3.0 hours to fully charge.
- After the battery is charged, leave the camera in the printer dock to maintain the full charge.
- The three green charging lights monitor the charging status (see Printer Dock Status Lights, page 47).





- 1 Battery is less than half charged.
- 2 Battery is more than half charged.
- 3 Battery is fully charged.


3 Printing Without a Computer



Printing from Your Camera


- 1 Make sure the AC power cord is connected and the color cartridge and paper are loaded (see Chapter 1, Getting Started with Your Printer Dock).
- 2 Take a picture with your camera.
- 3 Place the camera in the printer dock (see Chapter 2, Getting Started with Your Camera).




- 4 On the printer dock, press the Print Mode button to change print modes:

Tagged —prints pictures tagged for print in your camera's Share menu.


Current —prints the pictures displayed on the camera screen. Use the arrow keys  on the printer dock to select a picture.


All —prints all the pictures in your camera internal memory and memory card.

Index —prints index prints of all the pictures in your camera internal memory and memory card.

- 5 Press the Print  button.

The copy screen appears on your camera when current mode is highlighted on your printer dock.



Use the arrow keys  on the printer dock to select the number of copies to print, then press the Print button again.


Printing starts. The paper cycles four times during the printing process before the finished print is ejected. Each of the first three passes places a layer of color (cyan, yellow, and magenta). The fourth pass places a clear coating that protects and preserves the image quality.



CAUTION:


Wait until printing is complete before removing prints, the paper tray or the camera. Failure to do so can cause paper misfeeds or jams and can damage the printer dock.


Removing Perforated Tabs from Prints



- 1 Fold the side tabs away from the print.
- 2 Remove each side tab and discard.

Canceling Printing




- Press and hold the Print button  for 2 seconds.

The print job is immediately canceled and ejected into the paper tray. If you cancel a print during the fourth pass (clear coat), the print is ejected upon completion.


4 Reviewing Pictures and Videos

To review pictures and videos stored on your camera:



- 1 Make sure the power is connected to the printer dock (see Connecting the Power, page 5).
- 2 Place the Kodak EasyShare camera in the printer dock (see Docking and Charging the Camera, page 13).
- 3 Press the arrow keys  on the printer dock to scroll through the pictures and videos on your camera.

Running a Slide Show




Use the Slide Show to automatically review your pictures and videos, and to display pictures and videos on a television screen (see Displaying Pictures and Videos on a Television, page 20).

- 1 Make sure the power is connected to the printer dock (see Connecting the Power, page 5).
- 2 Place the Kodak EasyShare camera in the printer dock (see Docking and Charging the Camera, page 13).
- 3 Press the Slide Show button .

The pictures and videos are displayed in the order in which you took them. The slide show is finished when "The End" appears on the screen.

- To manually navigate through pictures and videos during the slide show, press the arrow keys  on the printer dock.
- To select images to print during the slide show, press the Print button  and select the number of copies to print.

IMPORTANT: *If, after you press the Print button, you decide not to print the picture, select 0 on the copies screen before resuming the slide show.*

- To resume the slide show, press the Print button  again or press the Slide Show button . If neither button is pressed, after a short time the slide show resumes automatically.
- To cancel the slide show, press and hold the Slide Show button  until "The End" appears on the screen.


When the slide show ends, all the pictures you selected are printed.

Changing the Slide Show Display Interval

Use your Kodak EasyShare camera settings to change the length of time slides are displayed in the slide show. See your camera user's guide for details.

Running a Continuous Slide Show Loop

When you turn on Loop on your Kodak EasyShare camera, the slide show is continuously repeated. See your camera user's guide for details.

- To cancel the slide show, press and hold the Slide Show button  until "The End" appears on the screen.


Displaying Pictures and Videos on a Television

You can display pictures and videos on a television, computer monitor, or any device equipped with a video input. (Images may not look as good on a television as on a computer monitor or when printed.)

An Audio/Video cable is required to connect to a television. Use the A/V cable that came with your Kodak EasyShare camera. To purchase one separately, see a retail dealer of Kodak products or visit www.kodak.com/go/printerdock.

You need at least one still image or video on your camera to display the picture on your television.

- 1 Make sure the power is connected to the printer dock (see Connecting the Power, page 5).





- 2 Connect the Audio/Video cable from the printer dock A/V out connector to the television video-in port.

- 3 Turn on your television, and change to a video channel.


See your television user's guide for details.

- 4 Place the Kodak EasyShare camera in the printer dock (see Docking and Charging the Camera, page 13).



- 5 Press the Slide Show button .

The camera screen turns off; the television screen acts as the camera display. If a picture does not appear on your television screen see Chapter 7, Troubleshooting.

- To manually navigate through pictures and videos during the slide show, press the arrow keys  on the printer dock.

For more information, see Running a Slide Show, page 19.

5 Using the Printer Dock with a Computer

System Requirements

Windows-based Computer


- Personal computer running Windows 98, 98SE, ME, 2000*, or XP*
- 233 MHz processor or greater
- 64 MB of RAM (128 MB for Windows XP)
- 200 MB of available hard disk space
- CD-ROM drive
- Built-in USB port
- Color monitor with a minimum resolution of 800 x 600 pixels; High Color (16-bit) or true color (24-bit) recommended
- Internet access for ordering supplies online

Mac OS X

- Power Mac G3, G4, G4 Cube; iMac Powerbook G3, G4; iBook
- Mac OS 10.1.5* minimum
- 128 MB of available RAM
- 200 MB of available hard disk space
- CD-ROM drive
- Built-in USB port
- Color monitor with a minimum resolution of 800 x 600 pixels; thousands or millions of colors recommended
- Internet access for ordering supplies online and for downloading software

* You must have Administrator rights to install software on these systems.

Installing the Software



CAUTION:

Do not install the Kodak EasyShare printer dock 6000 software with the printer dock connected to the computer. It may cause the software to load incorrectly. If the printer dock is connected, disconnect it before you proceed.

NOTE: For more information on installing the software, see the ReadMe file on the Kodak EasyShare printer dock 6000 software CD.

On a Windows-based computer:

- 1 Close all software applications that are open on your computer.
- 2 Place the Kodak EasyShare printer dock 6000 software CD into the CD drive.
- 3 Load the software:
 - a If an install window does not appear, select Run from the Start menu and type: `d:\setup.exe` (if `d` is the drive letter that contains the CD).
 - b Follow the on-screen instructions. Use the installer menus to select a language. If prompted, restart the computer when the installation is complete.

The Kodak EasyShare printer dock 6000 is added to your computer.

On Mac OS X:

- 1 Close all software applications that are open on your computer.
- 2 Place the Kodak EasyShare printer dock 6000 software CD into the CD drive.

- 3 Load the software:
 - a Double-click the CD icon on the desktop, then double-click the Kodak PD6000 Installer icon.
 - b Follow the on-screen instructions. Use the installer menus to select a language. When prompted, restart the computer.
 - c Open the finder window and click the Applications button. If you don't see the Applications button, access the Applications folder on your operating drive.
 - d Open the Utilities folder, then double-click Print Center.
 - e In the Printer List window, click the Add Printer button.
 - f Select Kodak PD6000, then click Add.

The Kodak EasyShare printer dock 6000 is added to your computer.

Uninstalling

On a Windows-based computer:

- 1 From the Start menu, select Settings, then select Control Panel.
- 2 Double-click Add/Remove Programs.
- 3 Select the Kodak PD6000 program, then click Remove. Follow the on-screen instructions. If prompted, restart the computer.
- 4 From the Start menu, select Settings, then select Printers.
- 5 Right-click the Kodak PD6000 printer icon, then select Delete.
- 6 Follow the on-screen instructions. **For Windows 2000 or Windows XP, continue to the next step. Otherwise stop here.**
- 7 From the Start menu, select Settings, then select Printers.
- 8 Select Server Properties from the File menu, then click the Drivers tab.
- 9 Select Kodak PD6000, then click Remove.
- 10 Click OK when complete.

On Mac OS X:

- 1 Double-click the operating drive for your system.
- 2 Select Library, then select Printers.
- 3 Open the Kodak folder, then double-click Kodak PD6000 Uninstaller. Follow the on-screen instructions.


Connecting to a Computer


A USB cable is required to connect to a computer. Use the USB cable that came with your Kodak EasyShare camera. To purchase one separately, see a retail dealer of Kodak products or visit www.kodak.com/go/printerdock.

**CAUTION:**

Make sure your camera is NOT in the printer dock when you are connecting to the computer.

- 1 Make sure the power is connected to the printer dock (see Connecting the Power, page 5), and the Kodak EasyShare printer dock 6000 software is installed on the computer (see Installing the Software, page 24).



- 2 Plug the labeled  end of a USB cable into the labeled USB port on your computer. See your computer documentation for details.
- 3 Plug the other end of the USB cable into the square USB connector on the back of the printer dock.
- 4 Route the cable through the channel located on the underside of the printer dock, so that the cable does not interfere with the paper path.

Transferring Pictures

You can transfer pictures directly from your Kodak EasyShare camera to your computer (see your camera user's guide), or with the camera docked, you can transfer pictures through the printer dock.

- 1 Make sure the Kodak EasyShare printer dock 6000 software is installed (see *Installing the Software*, page 24) and the printer dock is connected to your computer (see *Connecting to a Computer*, page 26).
- 2 Place the camera in the printer dock (see *Docking and Charging the Camera*, page 13).
- 3 Press the Transfer button on the printer dock.

A new drive appears for the printer dock, and the Kodak EasyShare software opens on your computer (if it is installed).

- 4 Use the Kodak EasyShare software to transfer pictures from the printer dock to your computer.

The printer dock Transfer light blinks green while the pictures are being transferred. Charging is suspended during transfer.

See your camera quick start guide or the Kodak EasyShare software Help for information on installing and using the Kodak EasyShare software.

NOTE: If the Kodak EasyShare software is not installed, you can transfer from the printer dock to your computer by copying pictures from the newly established printer dock drive to your computer hard drive. See your computer documentation for details.

Printing from a Computer

We recommend using the Kodak EasyShare software included with your Kodak EasyShare camera for printing. This software lets you to take advantage of a wide range of features, including full color enhancement, red eye reduction, picture organization, and much more.

See your camera quick start guide or the Kodak EasyShare software Help for information on installing and using the Kodak EasyShare software.

If there are no pictures on your computer, use the printer dock to transfer pictures from your camera before printing (see *Transferring Pictures*, page 27).

Printing with Kodak EasyShare software

- 1 Make sure the Kodak EasyShare printer dock 6000 software is installed (see *Installing the Software*, page 24) and the printer dock is connected to your computer (see *Connecting to a Computer*, page 26).
- 2 For borderless 4" x 6" prints, set the Kodak EasyShare software settings as follows:

On a Windows-based computer:

Paper size—4.0 x 6.0 in. (102 x 152 mm)

Paper type—Other or Kodak Photo Paper PH-10/40

Print layout—Full size

On Mac OS X:

Format for—Kodak PD6000

Paper size—Photo Paper

Print layout—Full size

Picture in print size—Fill

Turn on One-Touch to Better Pictures feature—No

- 3 Change any other settings as needed.
- 4 On the Print at Home screen, click Print.

Printing Using Other Applications

- 1 Make sure the Kodak EasyShare printer dock 6000 software is installed (see *Installing the Software*, page 24), and the printer dock is connected to your computer (see *Connecting to a Computer*, page 26).
- 2 Open the pictures you wish to print in the application from which you want to print.
- 3 Access printer settings by selecting **Print** or **Page Setup** from the **File** menu (depending on your application and platform).
- 4 Make sure that Kodak PD6000 is selected as the printer and that paper size in Windows is set to 4" x 6" (102 x 152 mm). On Mac OS X, make sure paper size is set to Photo Paper.
- 5 Change any other settings if needed, then click **OK** or **Print**. Depending on your application and platform, you may first need to return to the main menu and select **Print** from the **File** menu.

Kodak Color Mode

The Kodak EasyShare printer dock 6000 features two Kodak color mode options:

Natural—to get clear prints with no adjustment in color.

Enhanced—to get richer, more vivid colors from your pictures (default).

To change the Kodak color mode:

On Windows 2000/XP:

- 1 From the **Start** menu, select **Settings**, then select **Printers**.
- 2 Right-click the Kodak PD6000 printer icon, then select **Printing Preferences**.
- 3 Click the **Advanced** button.
- 4 Under **Document Options**, select **Printer Features**, then select **Kodak Color Mode**.
- 5 Select **Natural** or **Enhanced**, then click **OK**.
- 6 Click **OK** when complete.

On Windows 98/ME:


- 1 From the Start menu, select Settings, then select Printers.
- 2 Right-click the Kodak PD6000 printer icon, then select Properties.
- 3 Click the Printer Options tab.
- 4 Under Color Control, select Natural or Enhanced.
- 5 Click OK when complete.

On Mac OS X:

Make sure the Kodak PD6000 is selected as the current printer.


- 1 From an application File menu, select Print.
- 2 Use ▲/▼ to scroll through the available panels and select Color.
- 3 Select Kodak Color.
- 4 Choose Natural or Enhanced.
- 5 Click OK when complete.

Removing Perforated Tabs from Prints



- 1 Fold the side tabs away from the print.
- 2 Remove each side tab and discard.

Status Monitor—Windows only

The Kodak EasyShare printer dock 6000 status monitor icon  appears in the Windows taskbar in the lower-right corner of your computer screen. The status monitor provides information about the status of the printer and the current print job and lets you order supplies and accessories online.

Right-click the status monitor icon to select one of the following:

Open Status Monitor—displays the current printer status and job progress. You can also cancel the current print job (see *Canceling Printing*, page 31) and order supplies online.

Remove Icon from Taskbar—permanently removes the status monitor icon from the Windows taskbar (can be re-added by re-installing the software).

About Kodak Status Monitor—displays the version of the Kodak EasyShare printer dock 6000 status monitor.

Exit—temporarily disables the status monitor. The icon will reappear upon Windows startup.

Canceling Printing

On a Windows-based computer:

- 1 From the Start menu, select Settings, then select Printers.
- 2 Double-click the Kodak PD6000 printer icon.
- 3 Select the print job you want to cancel.
- 4 Select Document, then select Cancel.

NOTE: You may cancel the current print job using the status monitor (see *Status Monitor—Windows only*).

On Mac OS X:

- 1 In Print Center, double-click the Kodak PD6000 printer icon.
- 2 Click the job you want to cancel, then select Delete.

Ordering Supplies

For a full range of Kodak accessories and supplies, see your retailer of Kodak products or visit www.kodak.com/go/printerdock.


In addition, you can order printer dock supplies online using the Kodak EasyShare printer dock 6000 software.

On a Windows-based computer:

- 1 From the Start menu, select Settings, then select Printers.
- 2 Right-click the Kodak PD6000 printer icon, then select Printing Preferences (in Windows 2000/XP) or Properties (in Windows 98/ME).
- 3 Click the About tab.
- 4 Click Order Supplies.
- 5 Click OK when complete.


NOTE: You can also order supplies by double-clicking the status monitor icon in the taskbar (see Status Monitor—Windows only, page 31).

On Mac OS X:

- 1 From an application File menu, select Print.
- 2 Use  to scroll through the available panels and select Printer Support.
- 3 Click Order Supplies.

6 Care and Maintenance

General Care




- Keep the printer dock, accessories and supplies away from high temperatures, humidity and direct sunlight for extended periods of time.
- Support the printer dock and tray by placing it on a flat, level surface. Do not block the air vents.
- Avoid blocking the back of the printer dock and paper tray exit.
- Keep power and USB cables away from the paper path.
- Keep the printer dock clean.
- Keep the surrounding area vacuumed and litter-free.
- Protect the printer dock from tobacco smoke, dust, sand, and liquid spills.
- Avoid placing objects on the printer dock.

Cleaning the Print Head

Clean the print head when lines, streaks, or scratches appear on the prints. The head cleaning tool can be used several times, but should be replaced when the cleaning pad appears soiled or is no longer effective. Replacement cleaning tools are available at www.kodak.com/go/printerdock.


Use the print head cleaning tool to clean the print head.

- 1 Disconnect the power cord.
- 2 Open the color cartridge door.
- 3 Push up on the green lever and remove the color cartridge.




- 4 Insert the cleaning tool, white pad facing up, into the color cartridge slot.

IMPORTANT: *Do not touch or remove the white cleaning pad on the cleaning tool. The cleaning tool can only be inserted one way. Do not force it into the slot.*



- 5 Reinsert and remove the tool at least 3 to 4 times.
- 6 Reinstall the color cartridge (see Loading the Color Cartridge, page 6).
- 7 Close the color cartridge door.

Clearing a Paper Jam



- If a paper jam occurs, the Paper light flashes red. (see Indicator Lights and Buttons, page 9).




CAUTION:


Do not use force when removing the paper jam.

- 1 Remove the paper tray.
- 2 Disconnect the power cord, wait 5 seconds, then plug it back in.
- 3 The printer will reset and eject the paper. if the paper does not eject, try to remove it manually.
- 4 Replace the paper tray.
- 5 Press the Print button on the printer to resume printing.


Clearing a Color Cartridge Jam



- If a color cartridge jam occurs the cartridge light flashes red.



- 1 Open the color cartridge door.
- 2 Push up on the green lever and remove the color cartridge.



- 3 Remove the slack in the color cartridge by pushing in on the spool, then rotating the cartridge spool in the direction of the arrow.
- 4 Reinstall the color cartridge (see Loading the Color Cartridge, page 6).

Cleaning the Printer Dock




CAUTION:

Do not use abrasives or harsh chemicals to clean any part of the printer dock. Disconnect the power before cleaning.

Wipe the printer dock and the paper tray with a dry, lint-free cloth.

Traveling with your Printer Dock

IMPORTANT: *Protect the printer, accessories and supplies from high temperatures when transporting.*



- 1 Disconnect the power cord and remove all cables.
- 2 Remove the paper tray from the printer dock, and close the door.
- 3 Protect the paper by removing the protective cap from the front of the paper tray and placing it on the back of the paper tray.
- 4 Repack the printer dock in the original packing box, or use the optional printer dock travel bag. See a retail dealer of Kodak products or visit www.kodak.com/go/printerdock.

7 Troubleshooting

This chapter contains help for your printer dock.

For updates to Troubleshooting information, visit our Web site at www.kodak.com/go/printerdock.

Printing Problems

Printing		
Problem	Cause	Action/Solution
Paper misfeeds or pulls multiple sheets through the printer.	Too much paper is loaded in the paper tray, or the paper is improperly loaded.	Reload the paper (page 7), using no more than 25 sheets.
	The paper tray is improperly installed.	Re-install the paper tray (page 7).
Paper stops during mid-print, Paper or Cartridge lights flash.	The paper is jammed.	Clear the paper jam (page 35).
	The color cartridge is jammed.	Clear the cartridge jam (page 36).
Paper stops traveling before print is completed.	The removable tabs may be missing, causing the paper to misfeed.	Remove the paper tray and make sure removable tabs have not been detached. Reload with new paper if necessary (page 7).

Printing		
Problem	Cause	Action/Solution
Print is scratched along the length of the print.	The print head may need cleaning.	Clean the print head (page 34).
	The paper may be dusty or dirty.	Remove dirty paper.
Print is blank or light	The color cartridge is improperly installed.	Re-install the color cartridge (page 6).
	The color cartridge is empty.	Install a new color cartridge (page 6).
	The paper is loaded upside down.	Reload the paper with the print side facing up and Kodak logo facing down. (page 7).
	The wrong paper is loaded.	Use only Kodak color cartridge & photo paper kit PH-40.
Print is smudged.	There were fingerprints on the print side prior to printing.	Handle paper by the edges or by the removable tabs.
Print is spotted	The paper may be dusty or dirty.	Remove dirty paper.

Printing		
Problem	Cause	Action/Solution
Print is dark.	The captured image is too dark.	Try re-taking the picture under better lighting conditions or change the exposure compensation in your camera. Edit the picture using the computer and Kodak EasyShare software.
	High print head temperature.	Make sure the printer dock is not placed in direct sunlight or is not operating in a high-temperature environment. Let the printer dock cool down for 5 minutes.
	Cooling vents may be blocked or dirty.	Check that the cooling vents are not blocked or dirty (page 3).
Pictures are cropped.	Your camera is set at (4:3) aspect ratio.	Set your camera to Best (3:2) picture quality. Adjust cropped pictures using the computer and Kodak EasyShare software.

Printing		
Problem	Cause	Action/Solution
Nothing happens when you try to print.	The AC power cord is not securely connected.	Check the connections (page 5) and try again.
	The paper tray is improperly installed.	Remove the paper tray, check that paper is properly loaded, and re-install (page 7).
	The paper tray is empty.	Check that the paper light appears, then load paper (page 7).
	The color cartridge is improperly installed.	Re-install the color cartridge (page 6).
	The color cartridge is depleted.	Check that the color cartridge light appears, then install a new color cartridge (page 6).
...from the camera.	The camera is not in the printer dock or is improperly seated.	Replace the camera on the printer dock (page 13) and try again.
	There are no pictures in the camera.	Check the camera's internal memory and memory card.

Printing		
Problem	Cause	Action/Solution
...from the computer.	The USB cable is not securely connected.	Check the connections (page 26) and try again.
	The print job is paused or held in the print queue.	Access the printer menu for your system. Make sure no check mark appears next to the Pause Printing option.
	The battery monitor or similar software runs constantly.	Close that software before starting the Kodak software.
	The computer is transferring images.	Wait a few seconds, then try to print from the computer.
	The computer is unable to detect the printer dock or the camera.	<ol style="list-style-type: none"> 1 Finish the current print job (if in standalone mode). 2 End slide show (if it is running). 3 Check the connections (page 26) and try again.

Printing		
Problem	Cause	Action/Solution
...from the computer (continued).	There are too many applications running on your computer.	<ol style="list-style-type: none"> 1 Disconnect the USB cable from the printer dock (page 26). 2 Close all software applications. 3 Reconnect the USB cable (page 26) to the printer dock.
	Some Advanced Power Management utilities on laptops turn off ports to save battery life.	See the power management section of your laptop user's guide to disable this feature.
	The software is not fully or properly installed on the computer.	<ol style="list-style-type: none"> 1 Disconnect the USB cable from the printer dock. 2 Close all software applications. 3 Uninstall the software (page 24). 4 Re-install the Kodak EasyShare printer dock 6000 software (page 24). 5 Reconnect the USB cable to the printer dock (page 26).
	Computer is not running efficiently.	Consider upgrading your computer to meet the recommended system requirements (page 23).

Printing		
Problem	Cause	Action/Solution
Printing is slow.	High print head temperature.	Make sure the printer dock is not placed in direct sunlight or is not operating in a high-temperature environment. Let the printer dock cool down for 5 minutes.
	Cooling vents may be blocked or dirty	Check that the cooling vents are not blocked or dirty (page 3).
	Picture file size is large.	Check your computer configuration for memory.
	There are too many applications running on your computer.	<ol style="list-style-type: none"> 1 Disconnect the USB cable from the printer dock (page 26). 2 Close all software applications. 3 Reconnect the USB cable (page 26) to the printer dock.
	Computer is not running efficiently.	Consider upgrading your computer to meet the recommended system requirements (page 23).




Problems Transferring Pictures

Transferring Pictures		
Problem	Cause	Action/Solution
Cannot transfer pictures to the computer.	The Transfer button was not pressed.	Press the Transfer button.
	The AC power adapter or USB cable is not securely connected.	Check the connections (page 26) and try again.
	The camera was removed from the printer dock during picture transfer.	Replace the camera on the printer dock (page 13) and try again.
	There are too many applications running on your computer.	Close all software applications and try again.
	The software is not fully or correctly installed on the computer.	<ol style="list-style-type: none"> 1 Disconnect the USB cable from the printer dock. 2 Close all software applications. 3 Uninstall the software: (page 24). 4 Re-install the Kodak EasyShare software (page 24). 5 Reconnect the USB cable to the printer dock (page 26).

Printer Dock Status Lights

Cartridge Light		
Light Status	Cause	Action/Solution
Light glows steady red	The color cartridge is depleted.	Install a new color cartridge (page 6).
Light blinks red	The color cartridge is improperly installed.	Remove and re-install the color cartridge (page 6).
	There is a color cartridge jam.	Install a new color cartridge (page 6).
Light off	The color cartridge is properly installed.	None required.

Paper Light		
Light Status	Cause	Action/Solution
Light glows steady red	The paper tray is empty.	Load paper (page 7).
Light blinks red	The paper tray is improperly installed.	Remove the paper tray, check that paper is properly loaded, and re-install (page 7).
	There is a paper jam.	Clear the paper jam (page 35).
Light off	The paper tray is properly installed and has an ample supply of paper.	None required.

Battery Charging Lights		
Light Status	Cause	Action/Solution
No lights	Camera is not properly seated in the printer dock.	Place the camera in the printer dock (page 13) or readjust the camera placement.
	Camera is turned on.	Turn off the camera.
	Correct battery is not installed.	Install a Kodak EasyShare Ni-MH rechargeable battery pack or Kodak EasyShare Li-Ion rechargeable battery (page 11).
Green lights 	Battery is less than half charged.	Leave camera on dock to continue charging.
	Battery is more than half charged.	
	Battery is fully charged.	Leave camera on the dock to maintain charge.
One green light 	Camera was placed in camera dock.	None; dock is checking the charge status of the battery.
Red light (blinking) 	Battery is not properly installed.	Re-install the battery.
	Battery or connector pin is damaged.	Check for damage.
	Camera and battery have been exposed to extreme temperatures.	Slowly return the camera and battery to room temperature.

Print Mode Lights		
Light Status	Cause	Action/Solution
One light glows steady green	The respective print option is available and selected.	None required. To change modes, push the Print mode button repeatedly (page 9).
All lights are off	There are no pictures in the camera.	
	The camera is in (auto power-off).	Press the Print button or any button.

Print Light		
Light Status	Cause	Action/Solution
Light glows steady green	The printer dock is ready for printing.	None required.
Light blinks green	The printer dock is printing.	

Transfer Light		
Light Status	Cause	Action/Solution
Light glows steady green	The printer dock is ready for transferring pictures.	None required.
Light blinks green	Pictures are being transferred to the computer.	

Transfer Light		
Light Status	Cause	Action/Solution
Light is off	There are no pictures in the camera.	None required.
	The camera is not in the printer dock or is improperly seated.	Place the camera in the printer dock (page 13) or readjust the camera placement.
	The printer dock is not connected to the computer.	Connect the printer dock to the computer (page 23).
	The camera is in auto power-off.	Press any button.
	The printer dock is either printing in standalone mode or running a slide show.	The Transfer button is disabled.
	The computer is not running.	Turn on the computer.

8 Getting Help

Helpful Web Links

For help with your printer dock	http://www.kodak.com/go/printerdock
For help navigating through a Windows-based computer and working with digital pictures	http://www.kodak.com/go/pcbasics
To download firmware, printer dock drivers, and EasyShare software.	http://www.kodak.com/go/printdockdownloads
For product support on cameras, software, accessories, and more	http://www.kodak.com/go/camerasupport
To purchase a full range of digital camera and dock accessories	http://www.kodak.com/go/accessories

Help in this User's Guide

For help with problems you may have with your printer dock or computer connections, see Chapter 7, Troubleshooting.

Software Help

For help with the Kodak EasyShare printer dock 6000 software, see Installing the Software, page 24.

Telephone Customer Support

If you have questions concerning the operation of the software or printer dock, you may speak directly to a customer support representative.

Customer support hours vary by location.

Before You Call

If the printer dock is connected to a computer, please be at the computer, and have the following information available:

Operating system _____

Processor speed (MHz) _____

Computer model _____

Amount of memory (MB) _____

Exact error message you received _____

Version of installation CD _____

Printer dock serial number _____

Camera model _____

Telephone Numbers

Australia	1 800 147 701
Austria/Osterreich	0179 567 357
Belgium/Belgique	02 713 14 45
Brazil	0800 15 0000
Canada	1 800 465 6325
China	800 820 6027
Denmark/Danmark	3 848 71 30
Ireland/Eire	01 407 3054
Finland/Suomi	0800 1 17056
France	01 55 1740 77
Germany/Deutschland	069 5007 0035
Greece	00800 441 25605
Hong Kong	800 901 514
India	91 22 617 5823
Italy/Italia	02 696 33452
Japan	03 5644 5050
Korea	0798 631 0024
Netherlands/Nederland	020 346 9372
New Zealand	0800 440 786
Norway/Norge	23 16 21 33
Philippines	1 800 1 888 9600
Portugal	021 415 4125
Singapore	800 6363 036

Spain/España	91 749 76 53
Sweden/Sverige	08 587 704 21
Switzerland/Schweiz/Suisse	01 838 53 51
Taiwan	0080 861 008
Thailand	001 800 631 0017
UK	0870 243 0270
United States	1 800 235 6325
Outside the United States	585 726 7260
International Toll Line	+44 131 458 714
International Toll Fax Number	+44 131 458 962


For the most up-to-date listings, visit: <http://www.kodak.com/US/en/digital/contacts/DAInternationalContacts.shtml>.

9 Appendix

This appendix serves as a resource for technical information about your printer dock.

Printer Dock Specifications

Specifications—Printer Dock		
Printing Process		Thermal Dye Transfer
Operating Temperature-for best picture quality		49 to 95 ^o F (10 to 35 ^o C)
DC Voltage input		24 V DC at 1.8 Amps
AC Voltage		110 V to 240 V 50/60 Hz
Operating Humidity		10% to 86% Relative Humidity
Printer Dimensions (without insert)	Width	7.9 in. (20.1 cm)
	Depth	6.25 in. (15.8 cm)
	Height	3.0 in. (7.6 cm)
	Weight	38 oz (1.08 kg)
Printer Dimensions (without paper tray)	Width	7.9 in. (20.1 cm)
	Depth	6.25 in. (15.8 cm)
Printer Dimensions (with paper tray)	Depth	13 in. (33 cm)
Desk or surface space	Depth	18 in. (45.7 cm)
Paper tray	Width	4.75 in. (12 cm)
	Depth	7.75 in. (19.75 cm)

Specifications—Printer Dock		
Color cartridge	Width	3.14 in. (8 cm)
	Depth	5.21 in. (13.25 cm)
Photo size		4 x 6 in. (102 x 152 mm)
		 CAUTION: Do not use inkjet paper
Paper size		4 x 7.13 in. (102 x 181 mm)

Upgrading Your Software and Firmware

Take advantage of the latest enhancements to your Kodak software and printer dock firmware. Software refers to the applications included on the Kodak EasyShare printer dock 6000 software. Printer dock firmware is the internal software that runs on the printer dock.

To download the latest versions of software and firmware, visit www.kodak.com/go/printerdock.

Accessories and Supplies

Kodak accessories and supplies for the printer dock include:

Accessories and Supplies	
Item	Catalog Number
Kodak EasyShare printer dock 6000	823-7448
US w/sensormatic tag	867-0952
EAMER	120-9105
LAR	173-1801
GCR	140-9390
APR	149-5985
Canada	105-9948
Kodak color cartridge & photo paper kit (PH-40)	123-1349 (English) 116-5257 (Multi-lingual)
Audio/Video cable (included with camera)	198-3881
EasyShare Li-Ion batteries (1050 mAh)	849-9741
EasyShare Ni-MH rechargeable battery pack	114-8683
Kodak camera and printer dock travel bag	126-8903

For a full range of Kodak accessories and supplies, see your retailer of Kodak products or visit www.kodak.com/go/printerdock.

Safety Labels



RISK OF ELECTRIC SHOCK:

Do not open. Dry location use only.



CAUTION:

To avoid electrical hazard, use only with products specified in this user manual. Read all instructions before using.

Regulatory Information

FCC Compliance and Advisory

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed or used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: 1) reorient or relocate the receiving antenna; 2) increase the separation between the equipment and the receiver; 3) connect the equipment to an outlet on a circuit different from that to which the receiver is connected; 4) consult the dealer or an experienced radio/TV technician for additional suggestions.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Where shielded interface cables have been provided with the product or

specified additional components or accessories elsewhere defined to be used with the installation of the product, they must be used in order to ensure compliance with FCC regulation.



Canadian DOC Statement

DOC Class B Compliance—This Class B digital apparatus complies with Canadian ICES-003.

Observation des normes-Class B—Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Disposal Information

The printer dock and the AC adapter contain a small amount of lead in the circuit board. Disposal of this material may be regulated due to environmental considerations. For disposal or recycling information, contact your local authorities, or contact the Electronics Industry Alliance Web site at www.eiae.org.

Index

Numerics

800 number for customer support, 54

A

AC power connector, ii
accessories and supplies, 32, 51, 57

B

back view of printer dock, ii
batteries
 loading, 11—12
 ordering, 57
 status lights, 48
buttons and lights, 9
buying accessories and supplies, 57

C

cables, 26, 57
camera
 battery, loading, 11—12
 docking and charging, 13
 printing from, 15
Canadian compliance, 59

canceling printing, 17, 31
care and maintenance of printer dock, 33
cartridge door, color, iii
cartridges
 clearing jams, 36
 handling and storing, 6
 loading, 6
 specifications, 56
 status lights, 47
catalog numbers for accessories and supplies, 57
changing interval of slide show display, 20
charging
 batteries, 48
 the camera, 13
cleaning
 print head, 34
 printer dock, 36
clearance around printer dock, 3
clearing
 cartridge jams, 36
 paper jams, 35
color cartridge door, iii

- color cartridges
 - installing, 6
 - jams, clearing, 36
- color mode options, 29
- compliance with FCC
 - regulations, 58
- computer
 - connecting to, 26
 - helpful Web sites, 51
 - and printer dock, 23
 - printing from, 28
 - system requirements, 23
- connecting
 - to a computer, 26
 - power, 5
- contacting Kodak, 52—54
- contents of package, 2
- continuous loop for slide show, 20
- customer support
 - numbers, 52—54
- D**
- dimensions of printer, 55
- displaying
 - pictures and videos, 20
 - slide show interval, 20
- docking and charging the camera, 13
- door, color cartridge, iii
- E**
- electricity, connecting, 5, 55
- enhanced color mode, 29
- environmental requirements, 55
- F**
- FCC compliance, 58
- firmware, upgrading, 51, 56
- formatting page layout, 28
- front view of printer dock, i
- H**
- handling and storing
 - color cartridges, 6
 - paper, 8
- help
 - technical, 51—54, 56
 - telephone support, 52—54
 - troubleshooting printer dock, 39
- I**
- indicator lights and buttons, 9
- inserting paper tray, 8
- installing
 - cartridges, 6
 - software, 24

international phone
numbers, 53—54

interval of slide show,
changing, 20

J

jams, clearing, 35, 36
jobs, monitoring print, 31

K

Kodak
contacting, 52—54
EasyShare software, 28, 51
Web sites, 51

L

layout, formatting, 28
lights, status, 9, 47—49
loading
camera battery, 11—12
color cartridge, 6
paper, 7
software, 24
location for printer dock, 3
loop, slide show, 20

M

Macintosh system
requirements, 23
maintenance of printer dock, 33

modes, color, 29
monitor, requirements, 23
monitoring print job status, 31
moving printer dock, 37

N

natural color mode, 29
numbers, telephone, 53—54

O

operating temperature and
humidity, 55
ordering supplies, 32

P

package contents, 2
packing printer dock for
moving, 37
paper
formatting, 28
jams, clearing, 35
loading, 7
path, ii
specifications, 56
status light, 47
tray, i, 8
PC system requirements, 23
perforated tabs from prints,
removing, 16, 30

- pictures
 - reviewing, 19
 - setting quality, 12
 - transferring, 27
 - power, connecting, 5
 - print head, cleaning, 34
 - print job status, 31
 - Print Mode button and status lights, i, 49
 - printer dock
 - accessories and supplies, 57
 - back view, ii
 - care and maintenance, 33
 - cleaning, 36
 - and computer, 23
 - connecting, 26
 - front view, i
 - location and setup, 3
 - print head, cleaning, 34
 - side view, iii
 - specifications, 55
 - status lights, 47—49
 - technical help, 51—54, 56
 - travelling with, 37
 - troubleshooting, 39
 - upgrading, 51, 56
 - printer, status monitor, 31
 - printing
 - canceling, 17, 31
 - from camera, 15
 - problems, 39
 - with a computer, 28
 - with other applications, 29
 - problems
 - printing, 39
 - transferring pictures, 46
 - product support, 51, 56
- Q**
- quality, setting, 12
- R**
- regulatory information, 58, 59
 - removing perforated tabs from prints, 16, 30
 - requirements
 - environmental, 55
 - system, 23
 - resolving problems
 - with printing, 39
 - with transferring pictures, 46
 - reviewing pictures and videos, 19
 - running a slide show, 19
- S**
- service and support, 52—54
 - setting picture quality, 12
 - side view of printer dock, iii

slide show, running, 19

software

- help, 51
- installing, 24
- Kodak EasyShare, 28, 51
- printing with other, 29
- requirements, 23
- uninstalling, 25
- upgrading, 51, 56

specifications

- Macintosh OS, 23
- printer dock, 55
- Windows-based OS, 23

status lights, 47—49

status monitor, 31

storing color cartridges, 6

strap, wrist, 4

supplies and

- accessories, 32, 51, 57

support, technical, 51—54, 56

system requirements, 23

T

tabs from prints,

- removing, 16, 30

technical support, 51—54, 56

telephone numbers, 53—54

television, displaying pictures

- on, 20

temperature requirements, 55

toll free number for customer support, 54

Transfer button and status lights, 49

transferring pictures, 27, 46

travelling with printer dock, 37

tray, inserting paper, 8

troubleshooting

- cartridge jams, 36
- paper jams, 35
- printing problems, 39
- transferring pictures problems, 46

U

uninstalling software, 25

upgrading software, 51, 56

URLs for Kodak Web sites, 51

USB cable connections, ii, 26

V

videos, reviewing, 19

views of printer dock, i—iii

W

Web sites for Kodak, 51

weight of printer dock, 55

Windows system

- requirements, 23

wrist strap, 4

